
## FIGURE 5. FLEX TEST APPARATUS



Position "1", Left Extreme of Travel

Position "2", Right Extreme of Travel

End View